

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Carb Covers
Part No. 1-308

Fits Honda Valkyrie

Copyright© 2009 by Big Bike Parts, Inc.
No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

Revised: 2/2/2009

ITEMS REQUIRED: #2 PHILLIPS SCREWDRIVER
SMALL FLAT SCREWDRIVER
3/32" ALLEN WRENCH

IMPORTANT: READ STEP 4 THOROUGHLY BEFORE STARTING

INSTALLATION:

1. REMOVE THE THREE PHILLIPS SCREWS THAT HOLD THE RIGHT CHOKE LINKAGE GUARD IN PLACE, THIS IS THE LONG CHROME PIECE IMMEDIATELY BELOW THE CARB COVERS, REMOVE THE GUARD AND SET ASIDE.
2. CAREFULLY REMOVE THE TWO PHILLIPS SCREWS ON THE CHOKE LINKAGE. **NOTE** THE SCREWS HOLD WASHERS/SPACERS AND SPRINGS IN PLACE WITH LINKAGE BAR, BE CAREFUL NOT TO LOSE OR CHANGE ORDER.
3. LIFT THE LINKAGE BAR UP AND OUT OF THE WAY.

NOTE: THE THREE PHILLIPS SCREWS ON EACH CARB COVER HOLD DOWN ANOTHER INNER COVER, SPRING, NEEDLE AND DIAPHRAGM. (DO NOT ALLOW THE INNER COVER TO BE RAISED WHEN REMOVING CARB COVER IN NEXT STEP.)

4. REMOVE TWO SCREWS COMPLETELY, THEN WHILE HOLDING THE COVER DOWN, REMOVE THE LAST SCREW. USE A SMALL FLAT SCREWDRIVER INSERTED INTO ONE OF THE SCREW HOLES TO HOLD DOWN THE INNER COVER WHILE LIFTING OFF THE OUTER COVER. **NOTE:** THIS WILL PREVENT INNER COVER, SPRING, NEEDLE AND DIAPHRAGM FROM SPRINGING LOOSE.
5. REPLACE WITH NEW COVERS AND 4MM ALLEN HEAD SCREWS. REVERSE STEPS 1-4 TO REINSTALL. REPEAT FOR LEFT SIDE.

