

BIG BIKE PARTS®

INSTALLATION INSTRUCTIONS

LICENSE PLATE HOLDER

STANDARD 4 X 7 PLATES

PART # 16-130, 16-132

Copyright© 2006 by Big Bike Parts, Inc.® No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts Inc.®

Revised 08/12/2009

TOOLS NEEDED: 2.5MM ALLEN WRENCH 8MM WRENCH THREADLOCKER

INSTALLATION:

1. USING THE 2.5MM ALLEN WRENCH, SCREW THE FOUR SET SCREWS INTO THE FOUR HOLES ON THE BACK OF THE LICENSE PLATE HOLDER. APPLY THREADLOCKER ON THE SCREWS BEFORE INSTALLING.
2. CONNECT THE THREE WIRES AS FOLLOWS: FOR PART #16-130 - BLUE TO BRAKE, YELLOW TO RUNNING AND GREEN TO GROUND. 16-132 – RED TO BRAKE, BLUE TO RUNNING, AND BLACK TO GROUND. CRIMP THE MALE SPADES ONTO THE LICENSE PLATE WIRES AND CRIMP THE T-TAPS TO THE WIRES ON THE BIKE. SPLICE THESE WIRES INTO THE WIRE HARNESS FOR THE TAIL LIGHT.
3. PLACE THE LICENSE PLATE ONTO THE FOUR SET SCREWS SO THAT THE RED LIGHT IS TOWARDS THE TOP OR BOTTOM (YOUR PREFERENCE.) MAKE SURE THE WIRES ARE TUCKED INTO THE CHANNEL IN THE BACK OF THE HOLDER.
4. SET THE HOLDER AND PLATE INTO THE BRACKET ON THE BIKE. THIS MAY REQUIRE ONLY THE TOP TWO, BOTTOM TWO OR ALL FOUR OF THE SET SCREWS TO BE PLACED INTO THE MOUNTING HOLES ON THE BRACKET.
5. WITH THE HOLDER, PLATE, AND BRACKET ASSEMBLED TOGETHER TAKE THE FLAT WASHERS AND PLACE THEM ON THE SET SCREWS.
6. THREAD THE FOUR 5MM LOCK NUTS ONTO THE SET SCREWS. CENTER THE UNIT AND TIGHTEN WITH A 8MM WRENCH.
7. TEST FOR CORRECT OPERATION OF LED LIGHT.

BIG BIKE PARTS®

INSTALLATION INSTRUCTIONS

LICENSE PLATE HOLDER

STANDARD 4 X 7 PLATES

PART # 16-130, 16-132

Copyright© 2006 by Big Bike Parts, Inc.® No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts Inc.®

Revised 08/12/2009

TOOLS NEEDED: 2.5MM ALLEN WRENCH 8MM WRENCH THREADLOCKER

INSTALLATION:

1. USING THE 2.5MM ALLEN WRENCH, SCREW THE FOUR SET SCREWS INTO THE FOUR HOLES ON THE BACK OF THE LICENSE PLATE HOLDER. APPLY THREADLOCKER ON THE SCREWS BEFORE INSTALLING.
2. CONNECT THE THREE WIRES AS FOLLOWS: FOR PART #16-130 - BLUE TO BRAKE, YELLOW TO RUNNING AND GREEN TO GROUND. 16-132 – RED TO BRAKE, BLUE TO RUNNING, AND BLACK TO GROUND. CRIMP THE MALE SPADES ONTO THE LICENSE PLATE WIRES AND CRIMP THE T-TAPS TO THE WIRES ON THE BIKE. SPLICE THESE WIRES INTO THE WIRE HARNESS FOR THE TAIL LIGHT.
3. PLACE THE LICENSE PLATE ONTO THE FOUR SET SCREWS SO THAT THE RED LIGHT IS TOWARDS THE TOP OR BOTTOM (YOUR PREFERENCE.) MAKE SURE THE WIRES ARE TUCKED INTO THE CHANNEL IN THE BACK OF THE HOLDER.
4. SET THE HOLDER AND PLATE INTO THE BRACKET ON THE BIKE. THIS MAY REQUIRE ONLY THE TOP TWO, BOTTOM TWO OR ALL FOUR OF THE SET SCREWS TO BE PLACED INTO THE MOUNTING HOLES ON THE BRACKET.
5. WITH THE HOLDER, PLATE, AND BRACKET ASSEMBLED TOGETHER TAKE THE FLAT WASHERS AND PLACE THEM ON THE SET SCREWS.
6. THREAD THE FOUR 5MM LOCK NUTS ONTO THE SET SCREWS. CENTER THE UNIT AND TIGHTEN WITH A 8MM WRENCH.
7. TEST FOR CORRECT OPERATION OF LED LIGHT.