

Copyright © 2010 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 17-380, 17-385,
17-950 & 17-951

HEATED GRIPS
FOR ALL HONDA GOLDWINGS
EXCLUDING GL1800 WITH
COMFORT PACKAGE

4/16/2012

CAUTION: HEATED GRIPS CAN GET EXTREMELY HOT WHEN USED TO MAXIMUM TEMPERATURE. PLEASE USE CAUTION WHEN USING HEATED GRIPS.

ITEMS NEEDED: PHILLIPS SCREWDRIVER GRIP GLUE BBP#4-136 KNIFE
CLEANING SOLVENT (RUBBING ALCOHOL) SANDPAPER 80 GRIT

NOTE: PLEASE READ THROUGH ENTIRE INSTRUCTIONS BEFORE STARTING THE INSTALLATION

NOTE: PART NUMBERS 17-380, 17-385 & 17-951 COME WITH A NEW THROTTLE TUBE THAT MUST BE INSTALLED IN PLACE OF THE OEM THROTTLE TUBE.

1. REMOVE SEAT, IF NECESSARY (2001-2005 GL1800 EXCLUDED).
2. REMOVE HANDLEBAR WEIGHTS, IF APPLICABLE AND THE HANDLEBAR COVERS WITH A PHILLIPS SCREWDRIVER.
3. REMOVE BOTH GRIPS BY EITHER CUTTING THEM OFF OR TWISTING THEM OFF.
4. CLEAN THE HANDLEBAR AND THROTTLE TUBE OF ANY REMAINING GLUE LEFT BEHIND FROM THE OLD GRIP.
5. WITH ALL THE GLUE REMOVED FROM THE HANDLEBAR CLUTCH SIDE, LIGHTLY ROUGH THE SURFACE UP WITH SANDPAPER AND THEN CLEAN THE SURFACE WITH A MILD SOLVENT. LIGHTLY ROUGH UP INSIDE OF GRIP AND CLEAN.
6. INSTALL THE GRIPS ON THE BIKE WITH THE WIRES FROM THE GRIPS FACING FORWARD OR DOWNWARD. MAKE SURE THERE IS ENOUGH SLACK ON THE THROTTLE SIDE FOR MOVEMENT OF THE THROTTLE ITSELF.
7. BEFORE APPLYING GLUE FIT CHECK CLUTCH SIDE GRIP ONTO HANDLEBAR TO CHECK POSITIONING OF GRIP.
8. APPLY GRIP GLUE EVENLY AROUND HANDLEBAR APPROXIMATELY 2/3 OF THE GRIP LENGTH. CONTINUALLY IN A TWISTING MOTION SLIDE GRIP INTO PLACE ON HANDLEBAR. KEEP GRIP MOVING UNTIL IN DESIRED POSITION, ONCE YOU STOP GLUE WILL IMMEDIATELY HOLD TO HANDLEBAR AND YOU MAY NOT BE ABLE TO REMOVE WITHOUT DAMAGING NEW GRIP.
9. FOR THE THROTTLE SIDE USE THE NEW THROTTLE TUBE IF SUPPLIED, REMOVE THE NEW THROTTLE TUBE FROM GRIP, ROUGH THE SURFACE UP WITH SANDPAPER AND CLEAN THE SURFACE WITH A MILD SOLVENT AND LET COMPLETELY DRY. ROUGH INSIDE GRIP AND CLEAN AS WELL.
10. ONCE NEW THROTTLE TUBE IS CLEAN AND DRY, FIT CHECK THROTTLE TUBE AND GRIP ONTO BIKE AND MARK DISTANCE NEEDED BETWEEN GRIP AND THROTTLE TUBE FOR GRIP CLEARANCE FROM SWITCH BOX HOUSING AND POSITION OF CORD.
11. REMEMBER ONCE YOU APPLY GLUE TO THROTTLE TUBE YOU MUST KNOW THE CORRECT POSITION BEFORE GETTING TO THE END OF THE TUBE (APPROX. 1/4") AND THE CORRECT ANGLE OF THE CORD GOING DOWN. THERE IS NO TIME FOR ADJUSTMENT ONCE YOU GLUE.
12. APPLY GRIP GLUE EVENLY AROUND THROTTLE SLEEVE APPROXIMATELY 2/3 OF THE GRIP LENGTH. CONTINUALLY IN A TWISTING MOTION SLIDE TUBE INTO PLACE IN GRIP. KEEP GRIP MOVING UNTIL IN DESIRED POSITION, ONCE YOU STOP GLUE WILL IMMEDIATELY HOLD AND YOU MAY NOT BE ABLE TO REMOVE WITHOUT DAMAGING NEW GRIP.
13. SLIDE THROTTLE SIDE GRIP AND TUBE ONTO HANDLEBAR AND RECONNECT THROTTLE CABLES.
14. WE RECOMMEND YOU ALLOW GLUE TO CURE FOR 24 HOURS BEFORE USE.

15. WIRE THE FUSED WIRE HARNESS TO THE ACCESSORY TERMINAL IN THE FUSE BOX. (RED GOES TO POSITIVE, BLACK GOES TO NEGATIVE).

NOTE: ON THE 2001-2005 GL1800 THE WIRE HARNESS IS NOT NEEDED. A CONNECTOR UNDER THE RIGHT SIDE PANEL ON THE OEM WIRE HARNESS WILL PLUG DIRECTLY INTO THE CONTROLLER.

16. FIND A PLACE TO POSITION THE TEMPERATURE CONTROLLER. (POSITION THE CONTROLLER SO IT IS EASILY ACCESSIBLE.) USE THE BACKING PLATE WITH THE ADHESIVE ON IT. YOU WILL NEED TO DRILL A 9/16" HOLE FOR THE WIRES. (GL1800 - PLACE CONTROLLER BELOW THE RIGHT SIDE POCKET ON THE BLACK PANEL. GL1500 - PLACE CONTROLLER ABOVE THE RADIO PANEL.)

17. CONNECT THE TEMPERATURE CONTROLLER TO THE FUSED WIRE HARNESS AND THE GRIPS TO THE TEMPERATURE CONTROLLER. IF NEEDED, USE ZIP TIES (NOT INCLUDED) TO KEEP THE WIRES OUT OF THE WAY.

18. TEST FOR FUNCTION. REINSTALL SEAT IF REMOVED AND HANDLEBAR COVERS. IT WILL TAKE THE GRIPS A FEW MINUTES TO WARM UP TO FULL TEMPERATURE WHEN TURNED ON.

CAUTION: HEATED GRIPS CAN GET EXTREMELY HOT WHEN USED TO MAXIMUM TEMPERATURE. PLEASE USE CAUTION WHEN USING HEATED GRIPS.

