

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 2-279

MIRROR ACCENTS
GL1500/6

CLEANLINESS

THE FINEST MATERIAL WILL NOT ADHERE TO A DIRTY, OILY SURFACE. A MILD SOLVENT, SUCH AS RUBBING ALCOHOL, APPLIED WITH A **CLEAN** LINT-FREE RAG WILL PREPARE THE SURFACE TO BE COVERED.

CAUTION:

IT IS **IMPERATIVE** THE MIRROR BACKS BE POSITIONED ACCURATELY THE FIRST TIME. TAKE THE TIME TO MAKE A TRIAL INSTALLATION BEFORE REMOVING THE PROTECTIVE BACKING. LOOK FOR A CLOSE FIT AROUND ALL EDGES, PAYING PARTICULAR ATTENTION TO WHERE THE PART RESTS WITH RESPECT TO THE OEM RUBBER GASKET AFTER THE BEST FIT HAS BEEN OBTAINED. ONLY AFTER YOU ARE SATISFIED, YOU CAN REAPPLY THE PART IN THE SAME POSITION SHOULD YOU REMOVE THE PROTECTIVE BACKING. **DO NOT** TOUCH THE ADHESIVE MATERIAL WITH YOUR FINGERS. GENTLY LOCATE THE PART IN PLACE AND CHECK FOR PROPER ALIGNMENT. IF ANY CHANGES ARE NECESSARY, LIFT ONE EDGE AND SLOWLY REMOVE. WHEN READY FOR FINAL INSTALLATION, APPLY SLOW, EVEN PRESSURE WITH A CLEAN, DRY RAG. PUSH FIRMLY AND RUB THE CENTER OUT TOWARDS THE EDGES.

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 2-279

MIRROR ACCENTS
GL1500/6

CLEANLINESS

THE FINEST MATERIAL WILL NOT ADHERE TO A DIRTY, OILY SURFACE. A MILD SOLVENT, SUCH AS RUBBING ALCOHOL, APPLIED WITH A **CLEAN** LINT-FREE RAG WILL PREPARE THE SURFACE TO BE COVERED.

CAUTION:

IT IS **IMPERATIVE** THE MIRROR BACKS BE POSITIONED ACCURATELY THE FIRST TIME. TAKE THE TIME TO MAKE A TRIAL INSTALLATION BEFORE REMOVING THE PROTECTIVE BACKING. LOOK FOR A CLOSE FIT AROUND ALL EDGES, PAYING PARTICULAR ATTENTION TO WHERE THE PART RESTS WITH RESPECT TO THE OEM RUBBER GASKET AFTER THE BEST FIT HAS BEEN OBTAINED. ONLY AFTER YOU ARE SATISFIED, YOU CAN REAPPLY THE PART IN THE SAME POSITION SHOULD YOU REMOVE THE PROTECTIVE BACKING. **DO NOT** TOUCH THE ADHESIVE MATERIAL WITH YOUR FINGERS. GENTLY LOCATE THE PART IN PLACE AND CHECK FOR PROPER ALIGNMENT. IF ANY CHANGES ARE NECESSARY, LIFT ONE EDGE AND SLOWLY REMOVE. WHEN READY FOR FINAL INSTALLATION, APPLY SLOW, EVEN PRESSURE WITH A CLEAN, DRY RAG. PUSH FIRMLY AND RUB THE CENTER OUT TOWARDS THE EDGES.

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 2-279

MIRROR ACCENTS
GL1500/6

CLEANLINESS

THE FINEST MATERIAL WILL NOT ADHERE TO A DIRTY, OILY SURFACE. A MILD SOLVENT, SUCH AS RUBBING ALCOHOL, APPLIED WITH A **CLEAN** LINT-FREE RAG WILL PREPARE THE SURFACE TO BE COVERED.

CAUTION:

IT IS **IMPERATIVE** THE MIRROR BACKS BE POSITIONED ACCURATELY THE FIRST TIME. TAKE THE TIME TO MAKE A TRIAL INSTALLATION BEFORE REMOVING THE PROTECTIVE BACKING. LOOK FOR A CLOSE FIT AROUND ALL EDGES, PAYING PARTICULAR ATTENTION TO WHERE THE PART RESTS WITH RESPECT TO THE OEM RUBBER GASKET AFTER THE BEST FIT HAS BEEN OBTAINED. ONLY AFTER YOU ARE SATISFIED, YOU CAN REAPPLY THE PART IN THE SAME POSITION SHOULD YOU REMOVE THE PROTECTIVE BACKING. **DO NOT** TOUCH THE ADHESIVE MATERIAL WITH YOUR FINGERS. GENTLY LOCATE THE PART IN PLACE AND CHECK FOR PROPER ALIGNMENT. IF ANY CHANGES ARE NECESSARY, LIFT ONE EDGE AND SLOWLY REMOVE. WHEN READY FOR FINAL INSTALLATION, APPLY SLOW, EVEN PRESSURE WITH A CLEAN, DRY RAG. PUSH FIRMLY AND RUB THE CENTER OUT TOWARDS THE EDGES.