BIG BIKE PARTS[®] INSTALLATION INSTRUCTIONS

Copyright [©] 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.	PART NO. 2-305 2-306	CORD CLIP GL1200 & GL1500/6 GOLDWING			
1. REMOVE THE STOCK RUBBER CLIPS AND THOROUGHLY CLEAN THE SURFACE WITH A SOFT CLOTH AND RUBBING ALCOHOL.					
2. MAKE SURE THE AREA YOU ARE GOING TO INSTALL THE NEW CORD CLIP ON IS AS FLAT A SURFACE AS POSSIBLE.					
3. WHEN YOU HAVE SELECTED THE PROPER PLACE, MAKE SURE THE CORD CLIP WILL BE MOUNTED SO THAT THE COMMUNICATIONS CABLE CLIPS TO IT PROPERLY, PEEL OFF THE TAPE ON YOUR CORD CLIP AND PRESS IT FIRMLY INTO PLACE. THE CORD CLIP FOR THE REAR OF THE BIKE MUST BE MOUNTED AS FAR AWAY FROM THE SEAT AS POSSIBLE TO ALLOW FOR EASY PLUG ACCESS.					
4. TO GUARANTEE A PERMANEN HAVE BEEN PROVIDED FOR Y MAKE THE PROPER SIZE HOLD	OUR CONVENIENCE. US				

BIG BIKE PARTS^{*} INSTALLATION INSTRUCTIONS

Copyright [©] 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.	PART NO. 2-305 2-306	CORD CLIP GL1200 & GL1500/6 GOLDWING
-------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------	--------------------------------------------

- 1. REMOVE THE STOCK RUBBER CLIPS AND THOROUGHLY CLEAN THE SURFACE WITH A SOFT CLOTH AND RUBBING ALCOHOL.
- 2. MAKE SURE THE AREA YOU ARE GOING TO INSTALL THE NEW CORD CLIP ON IS AS FLAT A SURFACE AS POSSIBLE.
- 3. WHEN YOU HAVE SELECTED THE PROPER PLACE, MAKE SURE THE CORD CLIP WILL BE MOUNTED SO THAT THE COMMUNICATIONS CABLE CLIPS TO IT PROPERLY, PEEL OFF THE TAPE ON YOUR CORD CLIP AND PRESS IT FIRMLY INTO PLACE. THE CORD CLIP FOR THE REAR OF THE BIKE MUST BE MOUNTED AS FAR AWAY FROM THE SEAT AS POSSIBLE TO ALLOW FOR EASY PLUG ACCESS.
- 4. TO GUARANTEE A PERMANENT INSTALLATION, A MACHINE SCREW AND NUT HAVE BEEN PROVIDED FOR YOUR CONVENIENCE. USE A 3/16" DRILL BIT TO MAKE THE PROPER SIZE HOLE.

BIG BIKE PARTS[®] INSTALLATION INSTRUCTIONS

Copyright [®] 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.	PART NO. 2-305 CORD CLIP 2-306 GL1200 & GL1500/6 GOLDWING			
1. REMOVE THE STOCK RUBBER CLIPS AND THOROUGHLY CLEAN THE SURFACE WITH A SOFT CLOTH AND RUBBING ALCOHOL.				
2. MAKE SURE THE AREA YOU ARE GOING TO INSTALL THE NEW CORD CLIP ON IS AS FLAT A SURFACE AS POSSIBLE.				
3. WHEN YOU HAVE SELECTED THE PROPER PLACE, MAKE SURE THE CORD CLIP WILL BE MOUNTED SO THAT THE COMMUNICATIONS CABLE CLIPS TO IT PROPERLY, PEEL OFF THE TAPE ON YOUR CORD CLIP AND PRESS IT FIRMLY INTO PLACE. THE CORD CLIP FOR THE REAR OF THE BIKE MUST BE MOUNTED AS FAR AWAY FROM THE SEAT AS POSSIBLE TO ALLOW FOR EASY PLUG ACCESS.				
	T INSTALLATION, A MACHINE SCREW AND NUT OUR CONVENIENCE. USE A 3/16" DRILL BIT TO E.			

BIG BIKE PARTS[®] INSTALLATION INSTRUCTIONS

Copyright [®] 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.	PART NO. 2-305 2-306	CORD CLIP GL1200 & GL1500/6 GOLDWING		
1. REMOVE THE STOCK RUBBER CLIPS AND THOROUGHLY CLEAN THE SURFACE WITH A SOFT CLOTH AND RUBBING ALCOHOL.				
2. MAKE SURE THE AREA YOU ARE GOING TO INSTALL THE NEW CORD CLIP ON IS AS FLAT A SURFACE AS POSSIBLE.				
3. WHEN YOU HAVE SELECTED THE PROPER PLACE, MAKE SURE THE CORD CLIP WILL BE MOUNTED SO THAT THE COMMUNICATIONS CABLE CLIPS TO IT PROPERLY, PEEL OFF THE TAPE ON YOUR CORD CLIP AND PRESS IT FIRMLY INTO PLACE. THE CORD CLIP FOR THE REAR OF THE BIKE MUST BE MOUNTED AS FAR AWAY FROM THE SEAT AS POSSIBLE TO ALLOW FOR EASY PLUG ACCESS.				
4. TO GUARANTEE A PERMANEN HAVE BEEN PROVIDED FOR YO MAKE THE PROPER SIZE HOLE	OUR CONVENIENCE. US			