BIG BIKE PARTS' INSTALLATION INSTRUCTIONS

SIX LIGHT TOUR FRONT FORK KIT NO. 2-514 FITS HONDA GL1500/6 GOLD WING WITH 1998 STYLE ROTOR COVERS

Copyright[©] 1999 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

Revised 7/25/2017

ITEMS REQUIRED: 8MM WRENCH, 10MM WRENCH, 5/32" DRILL BIT, PHILIPS SCREW DRIVER, PENCIL, MASKING TAPE

INSTALLATION:

- A. PULL OUTWARD & FORWARD TO REMOVE THE L/R FENDER SIDE COVERS (1A).
 B. USING 8MM WRENCH, REMOVE THE TWO BOLTS (1C) FROM L/H DISC COVERS (1B), BE CAREFUL NOT TO LOSE THE COLLARS.
 USING 10MM WRENCH REMOVE BOLT (1D), FROM TOP L/H SIDES TO REMOVE (1B) L/H DISC COVER.
- 2. PLACE A PIECE OF MASKING TAPE TO MARK THE LOCATION OF THE BOTTOM HOLE OF THE FORK LIGHT BRACKET, YOU WANT TO CAREFULLY PLACE THE BRACKET, WITH LIGHTS INSTALLED, IN PLACE TO FIND AN APPROXIMATE LOCATION FOR THE LOWER MOUNTING HOLE (1F).
- 3. PLACE THE FORK LIGHT BRACKET CAREFULLY ONTO THE DISC COVER, ALIGNING THE TOP HOLE WITH THE TOP HOLE IN THE DISC COVER AND THE BOTTOM MOUNTING HOLE IN THE DISC COVER GROOVE. MARK THE BOTTOM BRACKET SIDE LOCATIONS ON THE MASKING TAPE WITH A PENCIL. REMOVE THE FORK LIGHT BRACKET AND MARK THE CENTER OF THE TWO PENCIL MARKS TO FIND THE LOCATION FOR DRILLING THE BOTTOM MOUNTING HOLE.
- 4. USING A 5/32" BIT, DRILL A HOLE AT THE MARKED MOUNTING LOCATION, BEING CAREFUL NOT TO LET THE DRILL SCRATCH THE FINISH. REMOVE THE TAPE AND SMOOTH OUT ANY ROUGH EDGES SO THE BRACKET FITS FLUSH.
- 5. USING THE PROVIDED HARDWARE, MOUNT THE FORK LIGHT BRACKET TO THE BOTTOM MOUNTING HOLE PER FIGURE 1. RUN THE WIRING THROUGH THE OPEN SLOT OF THE DISC COVER UP TO THE BIKE NEXT TO THE BRAKE HOSE.
- 6. REINSTALL THE DISC COVERS BACK ON THE BIKE WITH THE TOUR FRONT FORK LIGHTS IN PLACE AS PER FIGURE 1, MAKING SURE THE WIRING IS OUT OF THE WAY AND SECURED TO THE BRAKE HOSE WITH THE ZIP TIES PROVIDED.
- 7. AS THE TOUR FRONT FORK LIGHTS ARE SELF GROUNDED TO THE BIKE YOU ONLY NEED TO WIRE THE POSITIVE LEAD TO AN ALWAYS ON HOT LEAD OR TO AN ACCESSORY SWITCH TO BE ACTIVATED ONLY WHEN DESIRED.

