BIG BIKE PARTS [®]		INSTALLATION INSTRUCTIONS			
Copyright [©] 2019 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.		PART NO. 21-353		VANTAGE HIGHWAY BOARDS	
3/19/2019				NG/GOLDWING TOUR	
TOOLS NEEDED:	5MM ALLEN WRENCH	6MM ALLEN WRENCH			REMOVABLE THREAD LOCK
	LATION TIME: 45 TO 60 MIN		RE BEGINNING. *USE REN	IOVABLE THREAD LOCK ON ALL F.	ASTENERS*
INSTALLATION: 1.	STARTING ON THE LEFT SI				
2.					
		THE REAR OF THE LEFT LOWER COWL TO RELEASE IT.			
		OR REFERENCE, CAREFULLY RELEASE THE LEFT LOWER COWL TAB FROM THE LOWER SHROUD.			
5.		DMMET IN THE CENTER OF THE LEFT LOWER COWL (FIG. 4).			
6.	SLIGHTLY PULL OUT ON TI	HE BACK AND BOTTOM OF	THE LEFT LOWER COWL		TO RELEASE THE TAB HOLDING THE
7.				ISIDE OF THE LEFT LOWER COWL)	
8.			•	MOVE THE ENGINE GUARD COVER	
9.	PLACE ONE OF THE CLAM				. COVER WILL NOT BE REOSED.
10.					
11.	REFERENCE FIG. 6 TO INST	TALL THE CLAMP BOTTOM		HIGHWAY BOARD. (DO NOT TIGH N PLACE, TIGHTEN ALL BOLTS ANI	TEN. CLAMP CAN MOVE FORWARD
12.	. REPEAT ON THE RIGHT SIE	-	THE BOARD.) ONCE IT IS I		THE SET SCREW.
REMO			FT FOG LIGHT SOVER	SLIGHTLY T RELEASE	
	LEFT LOWER COWL TAB	LOWER		PULL STRAIGHT OUT TO RELEASE GROMMET	
FIG. 3		SHROUD LEFT EXHAUST HEAT SHIELD	-		FIG. 4

