

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2008 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 21-423T CRUIS BOARD PASSENGER KIT
21-426T
21-623T
21-827T
21-928T

02/26/09

TOOLS NEEDED: NEEDLE NOSE PLIERS 3/16 ALLEN WRENCH 3MM ALLEN WRENCH 10MM WRENCH THREADLOCKER

WE RECOMMEND USING A SMALL AMOUNT OF THREADLOCKER ON ALL THREADED HARDWARE INSTALLED.

1. REMOVE THE OEM PIN (A) HOLDING YOUR OEM PEG TO THE BIKE THEN REMOVE OEM PEG. IF IT IS THE DRIVER PEG OBSERVE AS TO HOW THE SPRING IS INSTALLED ON THE OEM PEG.
2. USING THE 3MM ALLEN WRENCH AND 10MM WRENCH INSTALL THE WASHER (B), SET SCREW (C), AND ACORN NUT (D) TO THE CRUIS BOARD (E).
3. IF APPLICABLE INSTALL THE RUBBER WASHER (F) AND FLAT WASHER (G) ON THE SLIDER STEM PEG (H).
4. INSTALL THE SLIDER STEM PEG (H), SLIDER STEM ADAPTER (J), AND CRUIS BOARD (E) INTO THE OEM PEG MOUNT USING THE OEM PIN (A) AND SPRING IF APPLICABLE. SECURE THE OEM PIN WITH WHATEVER HARDWARE THAT WAS HOLDING IT ON FROM STEP #1.
5. USING A 3/16 ALLEN WRENCH LOOSEN THE 5/16-18 BUTTON SOCKET HEAD CAP SCREW (K) AND ROTATE THE CRUIS BOARD (E) TO YOUR DESIRED LOCATION AND TIGHTEN BACK DOWN.
6. REPEAT STEPS 1-5 FOR THE OTHER SIDE.

