BIG BIKE PARTS

Copyright© 2005 by Big Bike Parts, Inc.® No part of this instruction sheet may be reproduced without the written permission of Big bike Parts, Inc. ®

INSTALLATION INSTRUCTIONS

DRIVER FOOTPEG LOWERING BRACKET USE WITH BBP 52-659 MOUNT PART NO. 21-520 HONDA GL1800 GOLDWING

8/26/2010

TOOLS NEEDED: NEEDLE NOSE PLIERS

INSTALLATION:

- REMOVE THE PEG FROM THE DRIVER PEG MOUNT BRACKET, BY REMOVING THE COTTER PIN AND THE PEG PIN.
- INSTALL THE NEW PEG LOWERING BRACKET ONTO THE DRIVER PEG MOUNT REUSING PEG PIN AND COTTER PIN REMOVED IN STEP 1.
- 3. ATTACH THE PEG TO THE NEW PEG LOWERING BRACKET USING PEG PIN AND COTTER PIN PROVIDED. MAKE SURE TO USE WASHERS PROVIDED ON THE TOP AND BOTTOM OF PEG PIN ON THE OUTSIDE OF NEW PEG LOWERING BRACKET.
- 4. REPEAT STEPS 1-4 FOR THE OTHER SIDE.
- 5. NOTE: THERE ARE TWO SETTINGS ON THE PEG LOWERING BRACKET, USE THE ONE THAT IS MOST COMFORTABLE FOR YOUR NEEDS. ALSO THESE NEW BRACKETS MAKE THE PEGS GO OUT AND LOWER THAN STOCK PEGS, BE SURE TO MAKE YOURSELF AWARE OF THIS WHEN RIDING AS THE PEG WILL HIT THE ROAD SOONER THAN STOCK PEGS.

BIG BIKE PARTS

Copyright© 2005 by Big Bike Parts, Inc.® No part of this instruction sheet may be reproduced without the written permission of Big bike Parts, Inc. ®

INSTALLATION INSTRUCTIONS

DRIVER FOOTPEG LOWERING BRACKET USE WITH BBP 52-659 MOUNT

HONDA GL1800 GOLDWING

8/26/2010

TOOLS NEEDED: NEEDLE NOSE PLIERS

INSTALLATION:

1. REMOVE THE PEG FROM THE DRIVER PEG MOUNT BRACKET, BY REMOVING THE COTTER PIN AND THE PEG PIN.

PART NO. 21-520

- 2. INSTALL THE NEW PEG LOWERING BRACKET ONTO THE DRIVER PEG MOUNT REUSING PEG PIN AND COTTER PIN REMOVED IN STEP 1.
- 3. ATTACH THE PEG TO THE NEW PEG LOWERING BRACKET USING PEG PIN AND COTTER PIN PROVIDED. MAKE SURE TO USE WASHERS PROVIDED ON THE TOP AND BOTTOM OF PEG PIN ON THE OUTSIDE OF NEW PEG LOWERING BRACKET.
- 4. REPEAT STEPS 1-4 FOR THE OTHER SIDE.
- 5. NOTE: THERE ARE TWO SETTINGS ON THE PEG LOWERING BRACKET, USE THE ONE THAT IS MOST COMFORTABLE FOR YOUR NEEDS. ALSO THESE NEW BRACKETS MAKE THE PEGS GO OUT AND LOWER THAN STOCK PEGS, BE SURE TO MAKE YOURSELF AWARE OF THIS WHEN RIDING AS THE PEG WILL HIT THE ROAD SOONER THAN STOCK PEGS.