<b>BIG BIKE PARTS</b> <sup>®</sup>	INSTALLATION INSTRUCTIONS			
Copyright <sup>©</sup> 2016 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.	PART NO. 30-113		FLAG POLE KIT	
12/20/2016	FITMENT: VIC	TORY CC/CR/CCT	/MAGNUM/HARDBAI	LL 2010-NEWER
TOOLS NEEDED: 3MM ALLEN WRENCH	7MM SOCKET WRENCH	14MM WRENCH	CLEAN RAG/TOWEL	
PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING. ESTIMATED INSTALLATION TIME: 10 TO 20 MIN. THIS ITEM CAN BE MOUNTED ON BOTH THE RIGHT AND THE LEFT SADDLEBAG MOUNTS. INSTALLATION:				
1. REMOVE THE SADDLEBAG ON THE SIDE YOU ARE GOING TO MOUNT THE FLAG POLE.				
<ol> <li>CLEAN THE SURFACE OF THE SADDLEBAG MOUNT SHOWN IN FIG. 1 USING A CLEAN RAG.</li> <li>ATTACH THE MOUNTING BRACKET TO THE SADDLEBAG MOUNT AS SHOWN IN FIG. 2. USE A M4 LOCK WASHER ON BOTH SIDES AS SHOWN IN FIG. 2.</li> </ol>				
<ol> <li>LETTING THE SCREWS REST ON THE BOTTOM OF THE SLOTS USE A 3MM ALLEN WRENCH AND A 7MM SOCKET WRENCH TO TIGHTEN THE SCREWS.</li> </ol>				
5. PLACE THE FLAP POLE INTO THE LARGE HOLE ON THE MOUNTING BRACKET AND INSTALL THE 3/8" LOCK WASHER AND HEX NUT AS SHOWN IN FIG. 3.				
6. USING A 14MM WRENCH TIGHTEN THE HEX NUT.				
<ol> <li>REINSTALL THE SADDLEBAG YOU REMOVE IN STEP 1. CAREFULLY CLOSE THE SADDLEBAG LID MAKING SURE IT DOES NOT HIT THE MOUNTING BRACKET.</li> <li>IF IT HITS OR IS TOO CLOSE TO THE SADDLEBAG LID REMOVE THE SADDLEBAG AND ADJUST THE MOUNTING BRACKET TO BE CLOSER TO THE FENDER.</li> </ol>				
<ul> <li>9. REMOVE THE TOPPER FROM THE FLAG POLE AND SLIDE THE O-RING ABOUT 6 INCHES DOWN THE POLE. SEE FIG. 4.</li> </ul>				
10. INSTALL THE FLAG AND REINSTALL THE TOPPER ON THE FLAG POLE.				
SADDLEBAG MOUNT	FIG. 1		M4 LOCK MOUNTING	FIG. 2
LEFT SIDE SHOWN	NTING DTS	SADDLEBAG MOUNT	NUTS BRACKET	M4 X 14MM SCREWS
FIG. 3	DLE	FIG.	4	TOPPER
MOUNTING BRACKET	3/8" LOCK WASHER HEX NUT	O-RING FLAG POLE		FLAG