

ITEMS REQUIRED: PLIERS, FINE FILE, KNIFE, 1/2" DRILL BIT & DRILL (FILLER PLATE INSTALLATIONS ONLY)

INSTALLATION:

1. REMOVE THE LICENSE PLATE FROM THE LICENSE PLATE MOUNTING BRACKET. (SAVE THE MOUNTING BOLTS.)
2. CHECK TO SEE IF YOUR SIZE LICENSE PLATE FITS THE PLATE HOLDER OPENING (1A). IF NECESSARY, THE TWO BREAK-OFF END TABS (1B) CAN BE REMOVED WITH A PAIR OF PLIERS. ANY ROUGH EDGES CAN BE SMOOTHED WITH A FINE FILE OR KNIFE.
3. INSERT THE BOTTOM EDGE OF YOUR LICENSE PLATE, FACE FORWARD (2A), INTO THE TWO TABS (2B) AND PIVOT THE PLATE INTO THE FRAME WHILE ALIGNING THE FRAME BOLT SLOTS (1C) WITH THE BOLT HOLES.
4. BOLT THE FINISHED ASSEMBLY TO THE MOUNTING BRACKET, USING THE BOLTS REMOVED IN STEP 1. NOTE FOR CHROME FILLER PLATE INSTALLATIONS ONLY: IT MAY BE NECESSARY TO PRE-DRILL A 1/2" DIAMETER CLEARANCE HOLE IN THE FILLER PLATE FOR PASSING THE ELECTRICAL WIRES THROUGH TO THE REAR OF THE FILLER PLATE.
5. ATTACH THE ELECTRICAL WIRING AS NECESSARY, RED (+) TO RUNNING LIGHT, BROWN (+) TO BRAKE LIGHT AND BLACK (-) TO GROUND.

