

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2000 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big bike Parts, Inc.

PART NO. 51-323 SMOKE
PART NO. 51-328 CLEAR

FORK WIND DEFLECTORS
HONDA VALKYRIE
VALKYRIE INTERSTATE
HONDA VTX 1800

Revised 11/6/09

TOOLS NEEDED: 8MM ALLEN WRENCH 10MM WRENCH 1.5MM ALLEN WRENCH
3MM ALLEN WRENCH 4MM ALLEN WRENCH

INSTALLATION:

1. POSITION THE TWO PIECES OF THE CLAMP (1A) ONTO THE FORK (FIG. 1) APPROXIMATELY 3 1/2" DOWN FROM THE BOTTOM SIDE OF THE TRIPLE TREE, KEEPING THE 6MM THREADED HOLE (1B) FACING TO THE OUTSIDE OF THE BIKE. FASTEN THE TWO SIDES TOGETHER USING THE TWO M4 X .70 X 15MM SHOULDER SCREWS PROVIDED WITH CLAMP. DO NOT TIGHTEN COMPLETELY AT THIS TIME, JUST ENOUGH TO HOLD CLAMP IN PLACE.
2. ASSEMBLE THE MOUNTING BRACKET (1C), TWO RUBBER GASKETS (1D), FACE PLATE (1E), AND DEFLECTOR PANEL (1F) WITH THE M5 X .80 X 20MM SOCKET HEAD SCREWS (1G) AND NYLOC NUTS.
3. MOUNT THE DEFLECTOR PANEL AND BRACKET ONTO THE CLAMP WITH THE M6 X 1.00 X 20MM SOCKET HEAD SCREW AND STAR WASHER. (FIG. 2) DO NOT TIGHTEN THE CLAMP SCREWS FROM STEP 1 OR THE SET SCREWS.
4. TURN THE FRONT WHEEL ALL THE WAY TO THE RIGHT AND LEFT MAKING SURE THE DEFLECTOR DOES NOT HIT ON ANY OTHER PARTS. ADJUST THE DEFLECTOR ACCORDINGLY. NOW TIGHTEN THE CLAMP SCREW AND THE M3 X .50 X 5MM SET SCREWS.
5. REPEAT PROCEDURE FOR THE OTHER SIDE.

