BIG BIKE PARTS

Copyright[®] 2005 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.[®]

INSTALLATION INSTRUCTIONS

RADIATOR ACCENT GRILLE PART NO. 52-606, 52-750 FOR GL1800 GOLDWING

REVISED 2/12/2009

ITEMS REQUIRED: 5MM ALLEN WRENCH PHILLIPS SCREWDRIVER FLAT BLADE SCREWDRIVER

INSTALLATION:

- 1. USING FLAT BLADE SCREWDRIVER GENTLY PRY OFF FAIRING MOLDING (1A).
- 2. USING 5MM ALLEN WRENCH REMOVE THE FOUR BOLTS (1B) THAT ARE UNDER FAIRING MOLDING (1A).
- 3. USING PHILLIPS SCREWDRIVER REMOVE THE SCREW (2A) ON INNER FAIRING (2B).
- 4. REMOVE THE THREE TRIM CLIPS (2C) IN INNER FAIRING (2B).
- 5. OPEN THE CONTROL PANEL (1C) TO ACCESS THE TOP OF RADIATOR.
- 6. REMOVE THE TRIM CLIP THAT IS HOLDING THE RADIATOR GRILLE TO THE AIR VENT DUCT.
- 7. WHILE PULLING OUT ON FRONT FAIRING YOU CAN ACCESS THE RADIATOR GRILLE. REMOVE THE OEM RADIATOR GRILLE BY PULLING DOWN ON BOTTOM 2 TABS & RELEASE, PUSH UP ON RADIATOR GRILLE TO RELEASE TOP 2 TABS. MAY NEED TO USE A SCREWDRIVER TO HELP IN PRYING OFF.
- 8. INSTALL NEW RADIATOR GRILLE. MAKE SURE TABS ARE INTO PLACE ON RADIATOR.
- 9. FOLLOW STEPS 1-6 FOR THE OTHER SIDE.
- 10. REINSTALL PARTS REMOVED IN REVERSE ORDER.

