

INSTALLATION INSTRUCTIONS

CHROME SADDLEBAG MOLDING

PART NO. 52-612

FOR HONDA GL1800 GOLDWING

Copyright© 2001 by Big Bike Parts, Inc.
No part of this instruction sheet may be
reproduced without the written permission
of Big Bike Parts, Inc.©

Revised 2/12/2009

ITEMS REQUIRED: PHILLIPS SCREWDRIVER
RUBBING ALCOHOL

INSTALLATION:

1. REMOVE THE THREE SCREWS (1A) THAT HOLD THE RIGHT SIDE SADDLEBAG LID MOLDING (1B) ON.
2. REMOVE THE TWO SCREWS (1C) THAT HOLD THE RIGHT SIDE SADDLEBAG CORNER MOLDING (1D) ON. THERE IS ALSO ADHESIVE TAPE (1E) HOLDING THE CORNER PIECE ON.
3. INSTALL THE NEW CHROME MOLDING IN THE REVERSE OF REMOVAL. BE SURE TO CLEAN THE SURFACE THAT THE ADHESIVE TAPE WILL CONTACT WITH RUBBING ALCOHOL.
4. FOLLOW STEPS 1-3 FOR LEFT SIDE.

