

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2002 by Big Bike Parts, Inc.
No part of this instruction sheet may be
reproduced without the written permission
of Big Bike Parts, Inc.©

WINDSHIELD GARNISH

PART NO. 52-641

FOR HONDA GL1800 GOLDWING

Revised 2/16/09

ITEMS REQUIRED: 10MM WRENCH

INSTALLATION:

1. RELEASE THE HEIGHT ADJUSTMENT LEVER (1A) (LEFT & RIGHT).
2. PULL BACK THE RUBBER COVER (1B) OVER LEFT & RIGHT MIRRORS.
3. USING 10MM WRENCH REMOVE THE BOLT (2A), WASHER (2B) AND RUBBER WASHER (2C) ON BOTH SIDES. BE CAREFUL NOT TO DROP ANY OF THE HARDWARE.

NOTE: THE MIRROR CAN MOVE FORWARD TO HELP GAIN ACCESS TO BOLT.

4. PULL THE OLD WINDSHIELD GARNISH STRAIGHT (2D) OUT TO RELEASE THE BOSSES (2E) FROM THE GROMMETS (2F).
5. INSTALL THE NEW WINDSHIELD GARNISH IN THE REVERSE OF REMOVAL.

