

INSTALLATION INSTRUCTIONS CHROME LOWER SADDLEBAG AIR DAM SPOILER PART NO. 52-646 FOR HONDA GL1800 GOLDWING

Copyright© 2002 by Big Bike Parts, Inc.
No part of this instruction sheet may be
reproduced without the written permission
of Big Bike Parts, Inc.©

Revised 2/16/09

ITEMS REQUIRED: PHILLIPS SCREWDRIVER

INSTALLATION:

1. PLACE BIKE ON CENTER STAND.
2. USING PHILLIPS SCREWDRIVER REMOVE THE FOUR SCREWS (1A) HOLDING THE SADDLEBAG LID HINGE TO SADDLEBAG.
3. USING PHILLIPS SCREWDRIVER REMOVE THE SCREW (1C) FROM THE SADDLEBAG LID CYLINDER ARM (1D) AND THE SCREW FROM THE STOP CORD (1E).
4. USING PHILLIPS SCREWDRIVER REMOVE THE THREE SCREWS (2A) HOLDING THE AIR DAM (2B) TO THE SADDLEBAG LID. INSTALL THE NEW AIR DAM REUSING THE SCREWS.
5. REMOVE THE THREE TRIM CLIPS (2C) HOLDING THE REAR AIR DAM (2D) TO THE SADDLEBAG. INSTALL THE NEW REAR AIR DAM REUSING THE TRIM CLIPS.
6. REPEAT STEPS 2-5 FOR THE OTHER SIDE.
7. REINSTALL THE REMOVED SADDLEBAG LID.

