BIG BIKE PARTS[®]

Copyright© 2001 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.©

INSTALLATION INSTRUCTIONS

LOWER WIND DEFLECTORS PART NO. 52-660L, 52-661L, 52-662L, 52-664L, 52-665L, 52-666L, 52-667L, 52-668L HONDA GL1800 GOLD WING

Revised 9/8/2011

ITEMS REQUIRED: 5MM ALLEN WRENCH FLAT BLADE SCREWDRIVER PHILLIPS SCREWDRIVER

NOTE: MAKE SURE ALL SCREWS IN ASSEMBLY ARE SNUG. DO NOT OVER-TIGHTEN.

INSTALLATION:

- USING FLAT BLADE SCREWDRIVER GENTLY PRY OFF THE LEFT FAIRING MOLDING (1A) STARTING FROM THE BOTTOM. TAKE CARE SO AS NOT TO BREAK OFF MOUNTING LEGS.
- 2. USING 5MM ALLEN WRENCH, REMOVE THE BOLT (1B) LOCATED UNDER FAIRING MOLDING (1A).
- 3. PLACE THE WIND DEFLECTOR ASSEMBLY (2A) IN PLACE SO THAT THE MOUNTING BRACKETS FIT INTO THE GROOVE ON THE FAIRING.
- 4. SECURE INTO PLACE USING THE SOCKET HEAD BOLT (2B) REMOVED IN STEP 2 AND THE NEW PHILLIPS SCREW (2C) PROVIDED.
- 5. FOLLOW STEPS 1-4 FOR THE RIGHT SIDE.
- 6. REINSTALL THE FAIRING MOLDING (1A) ON BOTH SIDES PRESSING THE TOP IN FIRST AND GOING DOWN.



