

LED LICENSE PLATE FRAME PART NO. 52-692

Copyright© 2003 by Big Bike Parts, Inc.
No part of this instruction sheet may be
reproduced without the written
permission of Big Bike Parts, Inc.™

TOOLS REQUIRED: WIRE CRIMPERS
 PHILLIPS SCREWDRIVER
 SCISSORS

INSTALLATION:

1. USING A PHILLIPS SCREWDRIVER REMOVE THE FOUR SCREWS HOLDING THE BACK PLATE ON THE LICENSE PLATE FRAME.
2. PUT THE CLEAR ACRYLIC PIECE INTO PLACE ON THE INSIDE OF THE LICENSE FRAME.
3. CUT THE THIN FOAM TAPE INTO STRIPS AND USE IT TO KEEP THE CLEAR ACRYLIC IN PLACE. STICK THE TAPE TO THE CLEAR ACRYLIC AT EDGES AND STICK IT TO THE FRAME AT CORNERS OF CLEAR ACRYLIC PIECE.
4. MARK WHICH WIRES GO TO WHICH LENS.
5. THIS IS AN UNIVERSAL LICENSE FRAME, SO DEPENDING ON THE LOCATION OF YOUR BIKES LICENSE MOUNT YOU MAY NEED TO TAKE THE SET SCREWS OUT AND PUT THEM IN THE OTHER HOLES AND TURN THE BACK PLATE AROUND. THIS WILL ALLOW THE RED LENS TO BE ON TOP AFTER MOUNTING.
6. PLACE YOUR LICENSE PLATE INTO THE FRAME. AGAIN, THIS IS AN UNIVERSAL FRAME AND YOU MAY NEED TO TRIM EDGES OF LICENSE PLATE JUST A LITTLE TO GET IT TO FIT IN THE FRAME.
7. CUT THE THICKER FOAM PIECE INTO TWO PIECES AND PLACE IT ON THE INSIDE OF BACK PLATE LENGTHWISE ABOUT 1 ½" APART.
8. PUT THE BACK PLATE BACK ON AND TIGHTEN DOWN.
9. HOOK THE WIRES FOR THE LIGHTS UP TO THE WIRING ON YOUR BIKE. THE AMBER LENSES ARE FOR TURN SIGNALS SO YOU WILL HAVE TO FIND THE TURN SIGNAL WIRES AND TAP INTO THEM WITH THE RED WIRES FROM AMBER LENS. THE RED LENS IS YOUR CHOICE FOR EITHER BRAKE LIGHT OR RUNNING LIGHT. ALL BLACK WIRES ARE GROUNDS.