

Copyright© 2003 by Big Bike Parts, Inc.
No part of this instruction sheet may be
reproduced without the written
permission of Big Bike Parts, Inc.

TOOLS REQUIRED: 4MM ALLEN WRENCH
5MM ALLEN WRENCH
10MM WRENCH

1. ASSEMBLE THE PLASTIC CLIP (1A) TO THE PANEL (1B) USING M6 X 1.00 X 13MM LONG SCREW (1C), LOCKNUT (1D) AND PLASTIC WASHER (1E). DO NOT TIGHTEN DOWN.
2. ASSEMBLE THE METAL CLIP (1F) TO THE PANEL (1B) USING M6 X 1.00 X 13MM LONG SCREW (1G), LOCKNUT (1H) AND PLASTIC WASHER (1I). DO NOT TIGHTEN DOWN.
3. ATTACH THE PLASTIC CLIP TO THE VERTICAL CRASH BAR.
4. REMOVE THE LOWER SOCKET HEAD SCREW ON THE FRONT COWL.
5. USE THE M6 X 1.00 X 18MM LONG SCREW (1J) AND SPACER (1K) PROVIDED TO ATTACH THE METAL CLIP TO THE SCREW HOLE IN THE LOWER COWL.
6. TIGHTEN ALL SCREWS DOWN.
7. REPEAT FOR THE OTHER SIDE.

