

BIG BIKE PARTS®

Copyright© 2005 by Big Bike Parts, Inc.® No part of this instruction sheet may be reproduced without the written permission of Big bike Parts, Inc. ®

INSTALLATION INSTRUCTIONS

SPOILER DUAL FUNCTION HONDA GL1800 GOLDWING 2001-10
LIGHT CONVERTER
PART NO. 52-734

Revised 7-20-18

TOOLS NEEDED: PHILLIPS SCREWDRIVER
5MM ALLEN WRENCH
6MM ALLEN WRENCH

INSTALLATION:

1. USING 6MM ALLEN WRENCH, REMOVE THE TWO BOLTS HOLDING THE PASSENGER GRAB HANDLES ON EACH SIDE.
2. REMOVE THE SEAT.
3. USING PHILLIPS SCREWDRIVER, REMOVE THE SCREWS ON THE INSIDE OF TRUNK LID AND REMOVE THE TRUNK LID INNER LINER.
4. PLUG THE BLUE TWO PIN CONNECTORS FROM NEW WIRE HARNESS BETWEEN THE TWO PIN CONNECTORS FOR THE SPOILER LIGHT THAT IS BEHIND TRUNK LID INNER LINER.
5. USING 5MM ALLEN WRENCH, REMOVE THE FOUR ALLEN HEAD SCREWS THAT HOLD THE REAR FENDER TO THE BIKE. REMOVE THE FENDER.
6. RUN THE BLUE THREE-PIN CONNECTOR END OF NEW WIRE HARNESS DOWN ON THE OUTSIDE OF TRUNK AND INTO THE BACK OF BIKE.
7. PLUG THE BLUE THREE-PIN CONNECTORS INTO THE BLUE THREE-PIN CONNECTORS ON BIKE. THESE ARE LOCATED ON TOP OF THE SHELF BEHIND WHEEL INSIDE A BLACK RUBBER BOOT.
8. CHECK TO MAKE SURE THE SPOILER LIGHT NOW FUNCTIONS AS A RUNNING AND BRAKE LIGHT, AND THAT ALL LIGHTS STILL FUNCTION PROPERLY.
9. RE-INSTALL ALL REMOVED PARTS IN THE REVERSE OF REMOVAL.

BIG BIKE PARTS®

Copyright© 2005 by Big Bike Parts, Inc.® No part of this instruction sheet may be reproduced without the written permission of Big bike Parts, Inc. ®

INSTALLATION INSTRUCTIONS

SPOILER DUAL FUNCTION HONDA GL1800 GOLDWING 2001-10
LIGHT CONVERTER
PART NO. 52-734

Revised 7-20-18

TOOLS NEEDED: PHILLIPS SCREWDRIVER
5MM ALLEN WRENCH
6MM ALLEN WRENCH

INSTALLATION:

1. USING 6MM ALLEN WRENCH, REMOVE THE TWO BOLTS HOLDING THE PASSENGER GRAB HANDLES ON EACH SIDE.
2. REMOVE THE SEAT.
3. USING PHILLIPS SCREWDRIVER, REMOVE THE SCREWS ON THE INSIDE OF TRUNK LID AND REMOVE THE TRUNK LID INNER LINER.
4. PLUG THE BLUE TWO PIN CONNECTORS FROM NEW WIRE HARNESS BETWEEN THE TWO PIN CONNECTORS FOR THE SPOILER LIGHT THAT IS BEHIND TRUNK LID INNER LINER.
5. USING 5MM ALLEN WRENCH, REMOVE THE FOUR ALLEN HEAD SCREWS THAT HOLD THE REAR FENDER TO THE BIKE. REMOVE THE FENDER.
6. RUN THE BLUE THREE-PIN CONNECTOR END OF NEW WIRE HARNESS DOWN ON THE OUTSIDE OF TRUNK AND INTO THE BACK OF BIKE.
7. PLUG THE BLUE THREE-PIN CONNECTORS INTO THE BLUE THREE-PIN CONNECTORS ON BIKE. THESE ARE LOCATED ON TOP OF THE SHELF BEHIND WHEEL INSIDE A BLACK RUBBER BOOT.
8. CHECK TO MAKE SURE THE SPOILER LIGHT NOW FUNCTIONS AS A RUNNING AND BRAKE LIGHT, AND THAT ALL LIGHTS STILL FUNCTION PROPERLY.
9. RE-INSTALL ALL REMOVED PARTS IN THE REVERSE OF REMOVAL.