

Copyright © 2005 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

SADDLEBAG SCUFF PADS
PART NO. 52-742

GL1800 GOLDWING

Revised 04/25/07

1. **CHECK** – CHECK FIT OF PART SO YOU KNOW HOW IT GOES ON.
 2. **CLEANLINESS** – USE A MILD SOLVENT APPLIED WITH A CLEAN, LINT FREE RAG TO CLEAN THE SURFACE.
 3. **APPLICATION** – THERE IS ONLY ONE CHANCE TO INSTALL. LIFT ONE EDGE OF THE PROTECTIVE BACKING ENOUGH SO YOU CAN PEEL IT AWAY IF YOU HOLD THE PART IN POSITION. GENTLY POSITION THE ACCESSORY IN PLACE AND SLOWLY PEEL THE PROTECTIVE BACKING OFF WHILE ADHERING THE ACCESSORY IN PLACE. APPLY PRESSURE TO THE WHOLE PART FOR 30 SECONDS. PUSH FIRMLY IN PLACE.
 4. **MAINTENANCE** – THE ADHESIVE SHOULD BE ALLOWED TO SET FOR 72 HOURS BEFORE EXPOSURE TO RAIN OR WASHING.
- FAILURE TO INSTALL AN ACCESSORY AS PER THE ABOVE INSTRUCTIONS MAY VOID ANY IMPLIED OR WRITTEN WARRANTIES.**

