

INSTALLATION INSTRUCTIONS

AMBER OPERA LIGHTS

PART NO. 52-728 & 52-753

FITS HONDA GL1800 GOLDWING

Revised 2/16/09

TOOLS REQUIRED: 5MM WRENCH

1. REMOVE THE FAIRING TRIM MOLDING (1A) BY STARTING AT THE BOTTOM AND PULL IT OUT.
2. USING 5MM ALLEN WRENCH, REMOVE THE FOUR SCREWS (1B) UNDER TRIM MOLDING (1A).
3. PUSH THE MIRROR FORWARD AND OPEN THE RUBBER BOOT AROUND MIRROR TO REVEAL THE THREE-PIN CONNECTOR NEEDED TO PLUG LIGHTS INTO.
4. CLEAN THE AREA FORWARD OF THE AIRFOIL (1C) WITH RUBBING ALCOHOL.
5. PEEL THE ADHESIVE BACKING FROM TAPE AND STICK TO THE BACK OF OPERA LIGHT AND THEN PLACE THE OPERA LIGHT IN FRONT OF THE AIRFOIL (1C).
6. RUN THE WIRES UP INSIDE THE FAIRING AND CONNECT TO THE THREE-PIN CONNECTOR. MAKE SURE WIRES DO NOT TOUCH RADIATOR.
7. REPEAT STEPS 1 THROUGH 6 FOR OTHER SIDE.
8. REINSTALL ALL PARTS REMOVED IN THE REVERSE OF REMOVAL.

