

# BIG BIKE PARTS®

Copyright© 2005 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

# INSTALLATION INSTRUCTIONS

VISORED MIRROR TRIM  
PART NO. 52-727 & 52-747A  
PART NO. 52-752 & 52-755

FOR HONDA  
GL1800 GOLD

Revised 08-14-06

TOOLS NEEDED: PHILLIPS SCREWDRIVER  
RUBBING ALCOHOL

1. USING A PHILLIPS SCREWDRIVER REMOVE THE PHILLIPS HEAD SCREW ON THE BOTTOM OF MIRROR HOUSING AND REMOVE THE MIRROR.
2. PULL BACK THE RUBBER BOOT THAT IS BETWEEN THE MIRROR HOUSING AND THE FAIRING.
3. CLEAN THE EDGE OF THE MIRROR HOUSING WITH RUBBING ALCOHOL.
4. PLACE THE DOUBLE-SIDED TAPE ON THE EDGE OF THE MIRROR HOUSING AND PEEL OFF THE BACKING.
5. APPLY THE LED MIRROR TRIM TO THE MIRROR HOUSING AND PRESS FIRMLY FOR 30 SECONDS.
6. RUN THE WIRES INTO THE FAIRING AND CONNECT THEM TO THE THREE PIN CONNECTOR FOR THE TURNSIGNAL LIGHT.
7. REINSTALL THE MIRROR INTO THE MIRROR HOUSING.
8. REPEAT STEPS 1-7 FOR THE OTHER SIDE.

**NOTE: THE DOUBLE SIDED TAPE IS NOT ATTACHED TO THE PART. IT IS BETTER TO PLACE THE TAPE ON THE MIRROR HOUSING AND THEN ATTACH MIRROR TRIM TO HOUSING.**