

# BIG BIKE PARTS®

Copyright© 2005 by Big Bike Parts, Inc.  
No part of this instruction sheet may be  
reproduced without the written permission  
of Big Bike Parts, Inc.

## INSTALLATION INSTRUCTIONS

RADIATOR GRILLE

FOR HONDA

PART NO. 1-216

SHADOW

PART NO. 53-109

ACE VT1100

PART NO. 53-114

PART NO. 53-146

Revised 1/21/04

TOOLS REQUIRED: 8MM WRENCH & 10MM WRENCH

### INSTALLATION:

1. USING THE 10MM WRENCH, REMOVE THE BOLT AT THE BOTTOM OF THE OEM RADIATOR TRIM AND THEN LIFT THE OEM RADIATOR TRIM OFF OF THE BIKE.
2. USING THE SAME WRENCH, REMOVE THE TOP RADIATOR MOUNT BOLT LEAVING THE RUBBER GASKET AND WASHER IN PLACE.
3. USING THE 8MM WRENCH, REMOVE THE NUT FROM THE BACK SIDE OF THE REFLECTORS AND REINSTALL THE REFLECTORS ON THE NEW CHROME TRIM.
4. SLIP THE NEW TRIM OVER THE TOP MOUNTING TABS AND SECURE USING THE TOP AND BOTTOM BOLTS REMOVED IN STEP ONE AND TWO.