

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright © 2004 by Big Bike Parts, Inc.™ No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.™

NECK COVERS
PART NO. 53-412

HONDA VT750 ACE

TOOLS NEEDED: PHILLIPS SCREWDRIVER
8MM WRENCH
12MM WRENCH

NOTE: IT IS RECOMMENDED TO HAVE TWO PEOPLE WHEN INSTALLING THIS PART.

1. REMOVE THE PASSENGER AND DRIVER SEAT.
2. USING A 12MM WRENCH, REMOVE THE BOLT AT THE BASE OF THE TANK THAT HOLDS THE TANK ON. NOW PULL THE TANK BACK TO ACCESS THE NECK COVERS. HAVE THE OTHER PERSON HOLD THE TANK SO IT DOES NOT FALL.
3. REMOVE THE BLACK METAL CLIP IN THE TOP OF THE OEM COVER AND REMOVE THE BLACK PLASTIC SCREW ON EACH SIDE. THERE IS ALSO A BLACK RUBBER SPLASH GUARD THAT IS HOOKED TO BOTH SIDES OF THE OEM NECK COVERS. NOW REMOVE THE NECK COVERS.
4. INSTALL THE NEW NECK COVERS IN REVERSE OF REMOVAL.
5. REINSTALL THE TANK AND SEATS IN REVERSE OF REMOVAL.