

BIG BIKE PARTS®

Copyright© 2004 by Big Bike Parts, Inc.™ No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.™

INSTALLATION INSTRUCTIONS

NECK COVERS
PART NO. 53-426

FITS HONDA
VT750 AERO

TOOLS NEEDED: 12MM SOCKET WRENCH
 8MM WRENCH
 5MM ALLEN WRENCH
 6MM ALLEN WRENCH

NOTE: TWO PEOPLE ARE NEEDED FOR THIS INSTALLATION.

NOTE: WE RECOMMEND USING LOC-TITE ON ALL BOLTS.

1. USING A 8MM WRENCH REMOVE THE BOLT BEHIND THE PASSENGER PILLOW SEAT.
2. USING A 6MM ALLEN WRENCH REMOVE THE TWO BOLTS ON THE SIDE OF THE DRIVER SEAT (ONE ON EACH SIDE) AND REMOVE THE TWO SEATS.
3. USING A 12MM SOCKET WRENCH REMOVE THE BOLT AT THE BOTTOM OF THE GAS TANK.
4. HAVE A SECOND PERSON PULL THE GAS TANK BACK AND HOLD IT SO YOU CAN REMOVE THE NECK COVERS.
5. REMOVE THE BLACK CLIP IN THE MIDDLE OF THE OEM NECK COVERS.
6. USING A 5MM ALLEN WRENCH REMOVE THE SCREW AT THE FRONT OF THE NECK COVERS ON EACH SIDE.
7. REMOVE THE OEM NECK COVERS FROM THE BIKE.
8. INSTALL THE NEW NECK COVERS IN REVERSE OF REMOVAL.
9. REINSTALL THE TANK AND SEATS.