

**BIG BIKE PARTS®**

**INSTALLATION INSTRUCTIONS**

**NECK COVERS**

**FITS HONDA VT600 1998-'08**

**PART NO. 53-711**

Copyright © 2005 by Big Bike Parts, Inc.  
No part of this instruction sheet may be  
reproduced without the written permission  
of Big Bike Parts, Inc.

Revised 3/5/2012

**TOOLS NEEDED: PHILLIPS SCREWDRIVER**

1. BEGIN BY REMOVING THE SCREW FROM THE TOP OF THE STOCK NECK COVER.
2. REMOVE THE SMALL BLACK PLASTIC CENTERPIECE IN THE MIDDLE OF THE STOCK NECK COVERS (THERE ARE THREE PARTS TO THE NECK COVER). PULL OUTWARD UNTIL IT SNAPS OUT.
3. PULL OUTWARD ON BOTH NECK COVERS, GENTLY WIGGLE THE COVERS TO DISASSEMBLE THEM. THERE IS A TAB ON THE UNDERSIDE OF THE COVERS THAT WILL POP LOOSE.
4. INSTALL THE NEW NECK COVERS IN THE REVERSE OF DISASSEMBLY. REMEMBER TO BE CAREFUL WITH THE CHROME AND PUSH ON GENTLY. MAKE SURE THE BOTTOM TAB SETS INTO PLACE.
5. WHEN SNAPPING THE SMALL CENTER PIECE IN, START WITH THE LEFT SIDE AND SNAP GENTLY IN PLACE. PUT THE STOCK SCREW BACK IN AND TIGHTEN