

Revised 5/29/13

TOOLS NEEDED:      5MM ALLEN WRENCH                      6MM ALLEN WRENCH                      8MM ALLEN WRENCH

INSTALLATION:

1. REMOVE THE FRONT AND BACK COVERS OVER THE REAR FENDER STRUT BOLTS.
2. REMOVE THE FRONT AND REAR FENDER STRUT SCREWS.
3. INSTALL THE SADDLEBAG STAY USING THE NEW LONGER SCREWS PROVIDED.
4. REPEAT STEPS 1 THROUGH 3 FOR OTHER SIDE.