

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2003 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.™

GROOVED HANDLEBAR CLAMP
PART NUMBER 55-120

FITS HONDA
VTX 1800

TOOLS NEEDED: 6MM ALLEN WRENCH

INSTALLATION:

1. PROTECT THE GAS TANK WITH A TOWEL OR MECHANICS TANK APRON.

NOTE: HANDLEBARS BECOME LOOSE AND CAUTION SHOULD BE TAKEN TO PREVENT ANY DAMAGE.

2. REMOVE THE OEM POST RISER CLAMPS BY FIRST REMOVING THE PLUGS IN THE ALLEN HEAD SCREWS ON THE TOP OF THE CLAMP.
3. USING 6MM ALLEN WRENCH LOOSEN AND REMOVE THE FOUR ALLEN HEAD SCREWS AND THE TOPS OF THE CLAMP. REMOVE THE OEM CLAMP.
4. INSTALL THE NEW HANDLEBAR CLAMP IN THE REVERSE OF REMOVAL. PLACE THE RUBBER BETWEEN THE HANDLEBAR AND THE CLAMP WITH THE GROOVED SIDE UP.

NOTE: MAKE SURE TO GET THE HANDLEBARS BACK IN THE PROPER POSITION FOR YOUR COMFORT.