

INSTALLATION INSTRUCTIONS

CURVED SOLO RACK

PART # 55-126

FITS: HONDA VTX

RETRO 1800 & 1300

TOOLS NEEDED: 2MM ALLEN WRENCH 4MM ALLEN WRENCH
5MM ALLEN WRENCH 6MM ALLEN WRENCH

NOTE: WE RECOMMEND USING LOC-TITE ON BOLTS.

INSTALLATION:

1. USING 5MM ALLEN WRENCH, REMOVE THE BOLT AT THE REAR OF PASSENGER SEAT.
2. USING 6MM ALLEN WRENCH, REMOVE THE TWO SIDE BOLTS HOLDING THE STRAP OVER THE PASSENGER SEAT AND REMOVE THE PASSENGER SEAT.
3. USING 6MM ALLEN WRENCH, REMOVE THE BOLTS HOLDING THE PASSENGER SEAT MOUNTING BRACKET, AND REMOVE THE MOUNTING BRACKET.
4. CLEAN THE BOTTOM OF THE MOUNTING LEGS OF THE SOLO RACK WITH RUBBING ALCOHOL AND APPLY RUBBER PADS TO EACH MOUNTING LEG.
5. USING 5MM ALLEN WRENCH AND THE TWO M8 X 1.25 X 20MM LONG BOLTS INSTALL THE FRONT TWO BRACKETS INTO THE FRONT HOLES ON FENDER, LEAVE LOOSE , DO NOT TIGHTEN.
6. ATTACH THE REAR MOUNT TO THE SOLO RACK USING M4 X .70 X 20MM LONG FLAT HEAD SCREWS PROVIDED.
7. ATTACH FRONT OF RACK TO THE FRONT BRACKETS AND POSITION IN PLACE. ATTACH REAR BRACKET TO BIKE USING M6 X 1.00 X 20MM LONG BOLT PROVIDED.
8. MAKE SURE ALL BOLTS ARE SECURE.