BIG BIKE PARTS[®]

INSTALLATION INSTRUCTIONS PART NO. 55-308 REAR CALIPER COVER

Copyright[®] 2003 by Big Bike Parts, Inc.[™] No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.[™]

Revised 5/18/04

TOOLS NEEDED: 12MM WRENCH

14MM WRENCH

5MM ALLEN

HONDA VTX 1300

INSTALLATION:

- 1. USING A 12MM WRENCH REMOVE THE BOLT AT THE LOWER LEFT OF THE CALIPER. THIS BOLT WILL NOT BE REUSED.
- 2. USING A 14MM WRENCH REMOVE THE BOLT AT THE TOP RIGHT OF THE CALIPER. THIS BOLT WILL BE REUSED.
- INSTALL THE CALIPER COVER REUSING THE BOLT REMOVED IN STEP #2. USE THE NEW M8 X 1.25 X 50MM LONG SOCKET HEAD SCREW PROVIDED IN THE HOLE WHERE THE BOLT IN STEP #1 WAS REMOVED. USE THE SPACER PROVIDED ON THE SOCKET HEAD SCREW ON THE INSIDE OF THE CALIPER COVER.

NOTE: WE RECOMMEND USING LOC-TITE ON BOLTS.