

# **BIG BIKE PARTS®**

# **INSTALLATION INSTRUCTIONS**

Copyright© 2003 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Part, Inc.™

**NECK COVERS**  
**PART NUMBER 55-314**

**FITS HONDA**  
**VTX 1300**

## **INSTALLATION:**

1. USING 5MM AND 6MM ALLEN WRENCHES REMOVE THE PASSENGER PILLOW SEAT.
2. USING 6MM ALLEN WRENCH REMOVE THE DRIVERS SEAT.
3. USING 12MM WRENCH REMOVE THE BOLT AT THE BOTTOM OF GAS TANK.
4. PULL THE GAS TANK BACK ABOUT 3 INCHES. (IT IS BEST TO HAVE ANOTHER PERSON HOLD THE TANK FOR YOU SO IT DOES NOT FALL OFF.)
5. REMOVE THE CLIP IN THE MIDDLE OF THE OEM NECK COVERS AND PULL THE TWO PIECES OF THE NECK COVERS OFF BIKE.
6. INSTALL THE NEW NECK COVERS IN REVERSE OF REMOVAL.
7. REINSTALL TANK AND SEATS.

**NOTE: WE RECOMMEND USING LOCTITE ON BOLTS.**