BIG BIKE PARTS[®]

Copyright© 2005 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc. 9/5/2012 **INSTALLATION INSTRUCTIONS**

Bullet Fork Covers Part No. 55-319 Fits VT750 AERO & Phantom; V Star 1100 Classic XVZ1300;XV1600; XV1700; VL800/C50 VTX 1300; VZ1600/M95; VT1300 S/R/T

ITEMS REQUIRED: 2.5MM ALLEN WRENCH

- 1. TAKE THE LEFT SIDE FORK COVER AND SLIDE IT ON THE LEFT FORK MAKING SURE THAT THE SMALL DRAIN HOLE ON THE BOTTOM OF THE COVER IS FACING THE REAR OF THE BIKE. TIGHTEN DOWN THE TWO SET SCREWS USING THE 2.5MM ALLEN WRENCH
- 2. INSTALL THE RIGHT SIDE THE SAME WAY YOU INSTALLED THE LEFT SIDE.