

BIG BIKE PARTS INSTALLATION INSTRUCTIONS

Copyright© 2001 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.©

PART # 62-104 FRONT FENDER RAIL
YAMAHA ROAD STAR

TOOLS REQUIRED: 13MM WRENCH
6MM ALLEN WRENCH

INSTALLATION:

1. USING 6MM ALLEN WRENCH REMOVE THE FOUR BOLTS HOLDING THE FENDER ONE AT A TIME AND INSTALL NEW LONGER BOLTS PROVIDED, DO NOT TIGHTEN.
2. INSTALL THE FENDER RAIL TO THE INSIDE OF FENDER.
3. TIGHTEN THE BOLTS DOWN AND USE THE LOCK NUTS PROVIDED ON END OF BOLTS.