

05/01/07

TOOLS NEEDED: 10MM SOCKET 3MM ALLEN WRENCH 4MM ALLEN WRENCH 5MM ALLEN WRENCH

1. REMOVE THE BOLT AT THE REAR OF THE PASSENGER SEAT AND THEN REMOVE THE PASSENGER SEAT.
2. USING A 10MM SOCKET REMOVE THE THREE BOLTS HOLDING THE METAL BRACKET THAT HELD THE FRONT OF THE PASSENGER SEAT.
3. ATTACH THE FRONT MOUNTING BRACKET (A) TO THE SOLO RACK (B) USING THE TWO SPACERS LABELED "FL" (C) AND "RF" (D), ("FL" IS THE LEFT FRONT AND "RF" IS THE RIGHT FRONT) AND TWO OF THE M5 COUNTERSUNK SCREWS (E) SUPPLIED. DO NOT TIGHTEN.
4. ATTACH THE REAR MOUNTING BRACKET (F) TO THE SOLO RACK (B) USING THE TWO SPACERS LABELED "RL" (G) AND "RR" (H), ("RL" IS THE REAR LEFT AND "RR" IS THE REAR RIGHT) AND TWO OF THE M5 COUNTERSUNK SCREWS (E) SUPPLIED. DO NOT TIGHTEN.
5. PLACE THE SOLO RACK ASSEMBLY ON THE REAR FENDER TO SEE HOW IT FITS. ROTATE THE SPACERS IF NEEDED UNTIL BOTH BRACKETS MATCH THE REAR FENDER THEN TIGHTEN DOWN THE FOUR M5 COUNTERSUNK SCREWS (E) WITH THE 3MM ALLEN WRENCH.
6. CLEAN THE BOTTOM OF THE FRONT (A) AND REAR (F) BRACKETS WITH A MILD SOLVENT SUCH AS RUBBING ALCOHOL. THEN ATTACH THE FRONT (I) AND REAR (J) RUBBER GASKETS TO THE CORRESPONDING BRACKETS.
7. PLACE THE SOLO RACK ASSEMBLY ON THE REAR FENDER. FASTEN THE REAR DOWN WITH THE SUPPLIED M8 BUTTON HEAD SCREW (K). USING THE SUPPLIED M6 BUTTON HEAD SCREW (L) AND A 4MM ALLEN WRENCH FASTEN THE FRONT SOLO RACK BRACKET TO THE BIKE. TIGHTEN DOWN BOTH THE M8 SCREW (K) AND M6 SCREW (L).

