

**BIG BIKE PARTS®**

# INSTALLATION INSTRUCTIONS

Chrome Neck Trim

Fits 650 V-Star

Part No. 63-120

Custom & Classic 1998-2001

Copyright© 2001 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts Inc.®

**TOOLS REQUIRED:**

10MM WRENCH

12MM WRENCH

5MM ALLEN WRENCH

1. REMOVE THE SEAT USING THE 10MM WRENCH.
2. REMOVE THE TWO BOLTS AT THE REAR / SIDES OF THE GAS TANK, SLIDE THE TANK BACK FAR ENOUGH TO REMOVE THE FRONT TANK MOUNT RUBBERS OFF THE MOUNTS UNDER THE FRONT OF THE TANK.
3. REMOVE THE SCREWS ON THE FRONT OF EACH OEM NECK PIECE USING THE 10MM WRENCH (THESE SCREWS WILL NOT BE RE-USED).
4. REMOVE BOTH OEM NECK TRIM PIECES & INSTALL THE NEW CHROME NECK TRIM USING THE NEW SOCKET HEAD SCREW & WASHERS (1 FLAT WASHER & 1 LOC WASHER ON EACH SIDE) TIGHTEN WITH THE 5MM WRENCH.
5. RE-ASSEMBLE BY REVERSING STEPS 1 THROUGH 2.