

**BIG BIKE PARTS®**

# INSTALLATION INSTRUCTIONS

Copyright© 2003 by Big Bike Parts, Inc.™ No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.™

**CHROME SIDE COVERS  
PART NO. 63-127**

**FOR YAMAHA XVS 650  
CLASSIC & CUSTOM**

8/17/2011

**TOOLS NEEDED:** 5MM ALLEN WRENCH  
CRESENT WRENCH

**INSTALLATION:**

1. USING 5MM ALLEN WRENCH REMOVE THE SCREW FROM THE RIGHT SIDE COVER.
2. REMOVE THE RIGHT SIDE COVER AND INSTALL THE NEW COVER REUSING THE SCREW.
3. USE KEY TO TAKE LEFT SIDE COVER OFF.
4. USE A CRESENT WRENCH TO REMOVE THE NUT ON THE KEY TUMBLER AND REMOVE THE TUMBLER. REMOVE THE GROMMET AROUND THE HOLE AND INSTALL IT ON THE NEW COVER AND INSTALL THE KEY TUMBLER INTO THE HOLE