

Copyright© 2005 by Big Bike Parts, Inc.® No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts Inc.®

4" PULL BACK HANDLEBAR RISERS PART #63-145

FITS V STAR 650 /
1100 CLASSIC &
CUSTOM
ROAD STAR

REVISED 1-18-05

TOOLS NEEDED: 6MM ALLEN WRENCH
19MM WRENCH

INSTALLATION:

1. PROTECT THE GAS TANK WITH A TOWEL OR A MECHANICS TANK APRON.

NOTE: HANDLEBARS WILL BECOME LOOSE AND CAUTION SHOULD BE TAKEN TO PREVENT ANY DAMAGE.

2. REMOVE THE OEM POST RISER CLAMPS BY FIRST REMOVING THE PLUGS IN THE ALLEN HEAD SCREWS ON THE TOP OF THE CLAMP.
3. USING A 6MM ALLEN WRENCH LOOSEN AND REMOVE THE FOUR ALLEN HEAD SCREWS AND THE TOPS OF THE CLAMPS.
4. AFTER REMOVING THE TOP CLAMPS AND SCREWS SET THE BARS ONTO THE TOWEL PROTECTING THE TANK.
5. USING A 19MM WRENCH REMOVE THE NUTS ON THE UNDERSIDE OF THE TOP FORK TREE THAT HOLD THE POST RISERS ONTO THE FORK TREE AND REMOVE THE OEM RISERS.
6. INSTALL THE NEW POST RISERS USING THE M12 X 1.25 X 65MM LONG BOLTS PROVIDED.
7. PLACE THE HANDLEBARS ON THE NEW RISERS AND PLACE NEW CLAMP TOPS ON TOP AND TIGHTEN DOWN REUSING OEM ALLEN HEAD SCREWS. REPLACE THE PLUGS IN THE ALLEN HEAD SCREWS.

NOTE: WHEN TIGHTENING THE POST RISER TOP CLAMPS:

1. CENTER THE HANDLEBARS.
2. ADJUST THE GRIP HEIGHT.

NOTE: STOCK CABLES MAY NEED TO BE REROUTED OR REPLACED FOR PROPER FITMENT