

# BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 63-208

SISSY BAR BACKREST KIT  
YAMAHA V-STAR 950/1300

08/02/2012

TOOLS NEEDED: 5MM ALLEN WRENCH 1/8" ALLEN WRENCH 13MM WRENCH THREADLOCKER

## HARDWARE INCLUDED:

1-(B) RIGHT REAR SPACER 1-(C) RIGHT FRONT SPACER 2-(D) 3.5MM REAR OUTSIDE SPACER 2-(E) 2MM FRONT OUTSIDE SPACER  
1-(K) LEFT REAR SPACER 1-(L) LEFT FRONT SPACER 3-(P) #10-32 X 1" FLAT HEAD CAP SCREW (BBP# S9103220PC)  
4-(S) M8-1.25 X 30MM BUTTON HEAD CAP SCREW (BBP# S5081230PC) 4-(T) M8-1.25 X 35MM BUTTON HEAD CAP SCREW (BBP# S5081235PC)  
4-(F) M8-1.25 X 50MM BUTTON HEAD CAP SCREW (BBP# S5081250PC) 2-(H) M8-1.25 X 80MM BUTTON HEAD CAP SCREW (BBP# S508128H)  
2-(G) M8-1.25 X 85MM BUTTON HEAD CAP SCREW (BBP# S5081285PC) 4-(R) M8-1.25 ACORN NUT (BBP# N80812PC)

**NOTE: WE RECOMMEND USING THREADLOCKER ON ALL HARDWARE INSTALLED.**

1. USING THE 5MM ALLEN WRENCH, REMOVE THE FRONT BOLT FROM THE RIGHT REAR FENDER CHROME TRIM AND INSTALL THE FRONT OF THE RIGHT SIDE BACKREST BRACKET (A), THE RIGHT FRONT SPACER (C), AND THE FRONT OUTSIDE SPACER (E), AS SHOWN, TO THE BIKE USING THE SUPPLIED M8-1.25 X 50MM BUTTON SOCKET HEAD CAP SCREW (F). DO NOT TIGHTEN DOWN ALL THE WAY.
2. USING THE 5MM ALLEN WRENCH, REMOVE THE REAR BOLT FROM THE RIGHT REAR RENDER CHROME TRIM AND ROTATE THE RIGHT SIDE BACKREST BRACKET (A) SO YOU CAN INSTALL THE RIGHT REAR SPACER (B), THE REAR OUTSIDE SPACER (D), AND THE REAR M8-1.25 X 50MM BUTTON SOCKET HEAD CAP SCREW (F). DO NOT TIGHTEN DOWN ALL THE WAY.

**NOTE: IF YOU HAVE SHOW CHROME SADDLEBAG STAYS (PART# 63-303) INSTALLED, YOU WILL NEED TO USE THE M8-1.25 X 80MM BUTTON HEAD CAP SCREWS (H) AND THE M8-1.25 X 85MM BUTTON HEAD CAP SCREWS (G) SUPPLIED. THE SADDLEBAG STAY WILL GO BETWEEN THE RIGHT BACKREST BRACKET (A) AND THE HEAD OF THE M8-1.25 X 80/85MM BUTTON HEAD CAP SCREW (H/G).**

3. REPEAT STEPS 1 AND 2 FOR THE LEFT SIDE.
4. FASTEN THE SISSY PAD (N) TO THE BACKREST BAR (M) USING THE 1/8" ALLEN WRENCH AND THE THREE 10-32 X 1.0" FLAT HEAD CAP SCREWS (P). MAKE SURE THE SISSY PAD (N) IS ON THE OPPOSITE FACE OF THE THREE COUNTERSUNK HOLES.
5. SLIDE THE BACKREST BAR WITH THE PAD INTO THE BACKREST BRACKETS AND LINE UP THE HOLES. THEN SLIDE THE FOUR M8-1.25 X 30MM BUTTON HEAD CAP SCREWS (S) IN AND TIGHTEN DOWN WITH THE FOUR M8-1.25 ACORN NUTS (R) SUPPLIED USING A 5MM ALLEN WRENCH AND THE 13MM WRENCH.

**NOTE: IF YOU ARE ALSO INSTALLING SHOW CHROME SISSY BAR RACK (PART# 55-322) YOU WILL USE THE FOUR M8-1.25 X 35MM BUTTON HEAD CAP SCREWS (T) SUPPLIED WITH THE RACK.**

6. TIGHTEN DOWN THE REMAINING FOUR BOLTS (F) HOLDING THE MOUNTING BRACKETS TO THE BIKE.

