

BIG BIKE PARTS®

Copyright© 2003 by Big Bike Parts, Inc.™ No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.™

INSTALLATION INSTRUCTIONS

CHROME SIDE COVERS YAMAHA XVS 1100 CLASSIC

PART NO. 63-606

REVISED 2-7-06

TOOLS NEEDED: 5MM ALLEN WRENCH
 PHILLIPS SCREWDRIVER
 CRESENT WRENCH

INSTALLATION:

1. USING 5MM ALLEN WRENCH REMOVE THE SCREW FROM THE RIGHT SIDE COVER.
2. REMOVE THE RIGHT SIDE COVER AND INSTALL THE NEW COVER REUSING THE SCREW.
3. USE KEY TO TAKE LEFT SIDE COVER OFF.
4. REMOVE THE TWO SCREWS HOLDING THE OEM CHROME BOSS PIECE AND INSTALL IT ON THE NEW COVER.
5. USE A CRESENT WRENCH TO REMOVE THE NUT ON THE KEY TUMBLER AND REMOVE THE TUMBLER. REMOVE THE GROMMET AOUND THE HOLE AND INSTALL IT ON THE NEW COVER AND INSTALL THE KEY TUMBLER INTO THE HOLE