

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2006 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 63-610

SADDLEBAG STAYS

FOR YAMAHA ROAD STAR, VSTAR 100 CLASSIC

TOOLS NEEDED: 5MM ALLEN WRENCH

1. USING A 5MM ALLEN WRENCH REMOVE THE FRONT LEFT SIDE BUTTON SOCKET HEAD CAP SCREW FROM THE LEFT REAR FENDER STRUT COVER. ALIGN THE FRONT LEFT SIDE SADDLEBAG STAY MOUNTING HOLE OVER THE EXISTING HOLE IN THE STRUT COVER MAKING SURE THAT THE SADDLEBAG STAY IS ANGLED OUT AND TOWARDS THE BACK OF THE BIKE. INSTALL ONE OF THE PROVIDED M8 SCREWS THROUGH THE SADDLEBAG STAY AND STRUT COVER INTO OEM HOLE AND HAND TIGHTEN.
2. USING A 5MM ALLEN WRENCH, REMOVE THE REAR LEFT SIDE BUTTON SOCKET HEAD CAP SCREW FROM THE LEFT REAR FENDER STRUT COVER. BE CAREFUL ONCE THE SECOND SCREW IS REMOVED, SO THAT THE COVER DOESN'T ROTATE AND SCRATCH THE FENDER. THEN ALIGN THE REAR LEFT SIDE SADDLEBAG STAY MOUNTING HOLE OVER THE EXISTING HOLE IN THE STRUT COVER. THEN INSTALL ONE OF THE PROVIDED M8 SCREWS THROUGH THE SADDLEBAG STAY AND STRUT COVER INTO THE OEM HOLE AND HAND TIGHTEN.
3. WITH A 5MM ALLEN WRENCH, TIGHTEN BOTH LEFT SIDE SADDLEBAG STAY SCREWS DOWN TIGHT.
4. REPEAT STEPS #1, 2, & 3 FOR THE RIGHT SIDE.