

BIG BIKE PARTS®

Copyright© 2005 by Big Bike Parts, Inc.® No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts Inc.®

INSTALLATION INSTRUCTIONS

PART # 71-110

**REGULATOR COVER
MARAUDER KAWASAKI
MEANSTREAK & DRIFTER**

Revised 06/05/07

**TOOLS NEEDED: 8MM SOCKET AND WRENCH
4MM ALLEN WRENCH**

INSTALLATION:

1. USING 8MM SOCKET REMOVE THE TWO BOLTS ON THE OEM REGULATOR COVER. PULL THE COVER OUT SLIGHTLY AND THEN PUSH BACKWARDS TO REMOVE THE TAB FROM RUBBER GROMMET.
2. REMOVE RUBBER GROMMET FROM OEM COVER AND PLACE INTO NEW PART.
3. PLACE SUPPLIED BOLTS THROUGH REGULATOR COVER ON BACKSIDE, PLACE SUPPLIED SPACERS ON BOLTS.
4. HOLDING BOLTS TIGHT TO THE COVER, SLIDE RUBBER GROMMET ONTO TAB ON BIKE. LINE UP BOLTS AND TIGHTEN WITH 4MM ALLEN WRENCH.

NOTE: WE RECOMMEND USING LOC-TITE ON BOLTS.

NOTE: ON VN1500 CLASSICS, THE TOP BOLT WILL GO THROUGH ONE OF THE SLOTS AND NOT THE MOUNTING HOLE.