

**BIG BIKE PARTS®**

# INSTALLATION INSTRUCTIONS

PART # 71-120, 71-121

V-STYLE RADIATOR GRILLE  
KAWASAKI VN2000

Copyright© 2006 by Big Bike Parts, Inc.® No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts Inc.®

Revised 9-6-06

TOOLS NEEDED: 4MM ALLEN WRENCH

INSTALLATION:

1. LOCATE AND REMOVE THE 4 RADIATOR SCREWS USING A 4MM ALLEN WRENCH.
2. REMOVE THE OEM RADIATOR COVER.
3. USING THE SUPPLIED HARDWARE, MOUNT THE NEW RADIATOR COVER ONTO THE BIKE. THE SMALL SPACERS GO BETWEEN THE RADIATOR COVER AND THE MOUNT ON THE BIKE.