

# **BIG BIKE PARTS®** INSTALLATION INSTRUCTIONS

Copyright© 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 71-314

**BRAKE RESERVOIR COVER  
FOR KAWASAKI VN900**

03-21-07

**TOOLS NEEDED:**

**8MM WRENCH**

**4MM ALLEN WRENCH**

1. USING AN 8MM WRENCH REMOVE THE SCREW HOLDING THE OEM BRAKE RESERVOIR COVER TO THE BIKE.
2. INSTALL THE CHROME BRAKE RESERVOIR COVER WHERE OEM COVER WAS REMOVED. WITH A 4MM ALLEN WRENCH TIGHTEN DOWN THE PROVIDED M6 BUTTON SOCKET HEAD CAP SCREW.