

# BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 71-318

HIGHWAY BARS  
KAWASAKI VN900 2006 -

10/11/07

ITEMS NEEDED: 14MM WRENCH 6MM ALLEN WRENCH 17MM WRENCH THREADLOCKER

**NOTE: WE RECOMMEND USING THREADLOCKER ON ALL HARDWARE INSTALLED.**

1. USING THE 14MM WRENCH, REMOVE THE TWO OEM BOLTS (A) LOCATED UNDER THE RIGHT SIDE FLOORBOARD, HOLDING THE FLOORBOARD BRACKET (B) TO THE FRAME (C).
2. SLIDE THE BOTTOM BRACKET (B) OF THE RIGHT SIDE HIGHWAY BAR (D) BETWEEN THE RIGHT SIDE FLOORBOARD BRACKET (B) AND THE FRAME (C) ALIGNING THE HOLES AND LOOSELY REINSTALL THE OEM BOLTS (A).
3. USING A 6MM ALLEN WRENCH AND A 17MM WRENCH, TIGHTEN THE BUTTON SOCKET HEAD CAP SCREW (E) AND ACORN NUT (F), INSTALL THE TOP MOUNTING BRACKET (G) CLAMPING THE TOP OF THE HIGHWAY BAR (D) TO THE FRAME (C). THE TOP OF THE MOUNTING BRACKET (G) GOES BEHIND THE FRAME (C).
4. TIGHTEN THE TWO OEM BOLTS (A) LOCATED UNDER THE FLOORBOARD.
5. REPEAT STEPS ONE THROUGH FOUR FOR THE LEFT SIDE.

