

BIG BIKE PARTS®

Copyright© 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

INSTALLATION INSTRUCTIONS

PART NO. 71-325

ABS NECK COVERS
KAWASAKI VN900

05/15/07

TOOLS NEEDED: 5MM ALLEN WRENCH 10MM SOCKET WRENCH PLIERS

1. USING THE 10MM SOCKET WRENCH, REMOVE THE HEX FLANGE HEAD BOLT FROM THE RIGHT SIDE OF THE NECK AND REMOVE THE WIRE BRACKET WHICH IT WAS HOLDING ON.
2. PLACE THE RIGHT SIDE OF THE NECK COVER OVER THE RIGHT SIDE OF THE NECK MAKING SURE THE THROTTLE CABLES RUN UNDER THE RIB ON THE BACKSIDE OF THE NECK COVER AND THE HEADLIGHT WIRE RUNS ABOVE THE RIB. THEN USING A 5MM ALLEN WRENCH, TIGHTEN DOWN THE RIGHT SIDE NECK COVER WITH ONE OF THE PROVIDED SOCKET HEAD CAP SCREWS.
3. USING A 10MM SOCKET WRENCH, REMOVE THE HEX FLANGE HEAD BOLT FROM THE LEFT SIDE OF THE NECK AND REMOVE THE WIRE BRACKET WHICH IT WAS HOLDING ON.
4. PLACE THE PROVIDED WIRE CLIP OVER THE OEM WIRES. THE CLUTCH CABLE GOES UNDER THE SMALL OPENING AND THE TWO CONTROLLER WIRES GO UNDER THE LARGE OPENING.
5. PLACE THE LEFT NECK COVER OVER THE LEFT SIDE OF THE NECK, ALIGNING THE HOLE IN THE COVER, WIRE CLIP, AND NECK. THEN USING A 5MM ALLEN WRENCH, TIGHTEN DOWN THE RIGHT SIDE NECK COVER WITH ONE OF THE PROVIDED SOCKET HEAD CAP SCREWS.
6. NEXT, SLIDE THE METAL CLIP OVER THE TWO FLANGES LOCATED AT THE TOP OF THE NECK COVER, USING A PLIERS IF NEEDED.