

3/30/09

**TOOLS NEEDED: PHILLIPS SCREWDRIVER**

1. REMOVE THE SEAT FROM THE BIKE BY INSERTING THE KEY INTO THE LOCK LOCATED IN THE LEFT SIDE COVER AND TURN KEY TO THE RIGHT.
2. USING THE PHILLIPS SCREWDRIVER REMOVE THE SCREW FROM THE TOP OF THE LEFT OEM SIDE COVER. REMOVE THE LEFT OEM SIDE COVER AND INSTALL THE NEW SIDE COVER REUSING THE SCREW. (NOTE: REMOVE THE WELLNUT FROM THE OEM SIDE COVER AND INSTALL IT IN THE NEW SIDE COVER BEFORE INSTALLING ON THE BIKE).
3. USING THE PHILLIPS SCREWDRIVER REMOVE THE SCREW FROM THE TOP OF THE RIGHT OEM SIDE COVER AND REMOVE THE RIGHT OEM SIDE COVER. THE LOWER OEM SIDE PANEL WILL ALSO NEED TO BE REMOVED AT THE SAME TIME BECAUSE THEY ARE ATTACHED.
4. REMOVE THE THREE SCREWS THAT ATTACH THE LOWER OEM SIDE PANEL TO THE OEM SIDE COVER AND REMOVE THE LOWER OEM SIDE PANEL. THEN REUSING THE THREE SCREWS, ATTACH THE NEW LOWER SIDE PANEL TO THE NEW SIDE COVER.
5. INSTALL THE NEW SIDE COVER AND NEW LOWER SIDE PANEL REUSING THE SCREW REMOVED IN STEP 3.
6. REINSTALL THE SEAT ON THE BIKE.