

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

SADDLEBAG STAYS
FOR SUZUKI VZ1600 MARAUDER
PART NO. 81-102

Copyright © 2005 by Big Bike Parts, Inc.
No part of this instruction sheet may be
reproduced without the written permission
of Big Bike Parts, Inc.

TOOLS NEEDED: 4MM ALLEN WRENCH

1. USING 4MM ALLEN WRENCH REMOVE THE TWO FENDER STRUT SCREWS.
2. INSTALL THE SADDLEBAG STAY USING THE M6 X 1.00 X 55MM LONG SOCKET HEAD SCREWS PROVIDED.
3. REPEAT STEPS 1 THROUGH 2 FOR OTHER SIDE.

NOTE: WE RECOMMEND USING LOC-TITE ON ALL SCREWS