

BIG BIKE PARTS®

INSTALLATION INSTRUCTIONS

Copyright© 2009 by Big Bike Parts, Inc®.
No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc®.

NECK COVERS
PART NO. 82-103

FITS SUZUKI
VL1500 1998-2004;
C90, C90T 2005

Revised 06/18/09

TOOLS NEEDED: 4MM ALLEN WRENCH

NOTE: INSTALL NEW CHROME NECK COVER VERTICALLY WITH BIKE.

1. USING A 4MM WRENCH, REMOVE THE BOLT AT THE BASE OF THE OEM NECK COVER ON THE RIGHT AND LEFT SIDE.
2. INSTALL THE NEW CHROME NECK COVER ON THE RIGHT SIDE BY SIMPLY HOLDING THE PART VERTICAL TO THE BIKE AND SLIDING IT UP INTO POSITION. THE PART WILL THEN LINE UP WITH THE ORIGINAL BOLT HOLE SO YOU CAN SECURE IT TO THE BIKE WITH THE OEM BOLT USING A 4MM ALLEN WRENCH.
3. REPEAT FOR LEFT SIDE AND YOU'RE READY TO RIDE.