

CNC CHROME DRIVER PEG MOUNT WITH LOWERING BRACKET PART NO. SPF520

Copyright© 2005 by Big Bike Parts, Inc.® No part of this instruction sheet may be reproduced without the written permission of Big bike Parts, Inc. ®

2/27/2014

TOOLS NEEDED: NEEDLE NOSE PLIERS
6MM ALLEN WRENCH

INSTALLATION:

1. REMOVE THE PEG FROM THE DRIVER PEG MOUNT BRACKET, BY REMOVING THE COTTER PIN AND THE PEG PIN.
2. REMOVE OEM MOUNTS USING 6MM ALLEN WRENCH. SAVE THE HARDWARE.
3. REPLACE OEM MOUNT WITH CNC CHROME MOUNT PROVIDED. INSTALL USING HARDWARE FROM PREVIOUS STEP.
4. INSTALL THE NEW PEG LOWERING BRACKET ONTO THE DRIVER PEG MOUNT REUSING PEG PIN AND COTTER PIN REMOVED IN STEP 1.
5. ATTACH THE PEG TO THE NEW PEG LOWERING BRACKET USING PEG PIN AND COTTER PIN PROVIDED. MAKE SURE TO USE WASHERS PROVIDED ON THE TOP AND BOTTOM OF PEG PIN ON THE OUTSIDE OF NEW PEG LOWERING BRACKET.
6. REPEAT STEPS 1-5 FOR THE OTHER SIDE.
7. **NOTE: THERE ARE TWO SETTINGS ON THE PEG LOWERING BRACKET, USE THE ONE THAT IS MOST COMFORTABLE FOR YOUR NEEDS. ALSO THESE NEW BRACKETS MAKE THE PEGS GO OUT AND LOWER THAN STOCK PEGS, BE SURE TO MAKE YOURSELF AWARE OF THIS WHEN RIDING AS THE PEG WILL HIT THE ROAD SOONER THAN STOCK PEGS.**